

INSTALLATION INSTRUCTIONS

Seamless Transaction with Enhanced Product Features delivered on time and quality correct.



01 FUNCTION

LATCH:

- A. Insert the latch (1) into the edge of the bore and attach using screws (2). Pre-drill for screws using 1/8" drill bit. Make sure the bevel on the latch tongue is facing the jamb. (The latch face is removable so that the bevel can be reversed to maintain the "up" position of the latch.)
- B. Install the strike and dust box to the jamb. Pre-drill for screws as per latch.

INSTALL TRIM:

- C. Orient spindle (3) in the diamond position and push through the latch (1) hub.
- D. Install the inside and outside trim (4) onto the spindle.
- E. Making sure that the plates are parallel with the edge of the door, position inside & outside trims for free and smooth operation. Install the four wood screws(5)to affix the plates to the door. We recommend the use of a #5 VIX bit to pilot the screw holes for these screws. (If you do not have one, use a 3/32 drill bit to pilot the holes.). Hand tighten screws; a power driver may strip them.

Corporate Address: 9546 Hwy 211 East - Aberdeen, NC 28315 Mailing Address: PO Box 367 - Aberdeen, NC 28315 Telephone: 866-635-7155 Website: www.longleafcollection.com Made in the USA